

## A little bit about your Energy Online Advanced Meter.

An Advanced Meter measures electricity usage in your home and allows wireless communications between your meter and Energy Online. The Advanced Meter used by Energy Online uses a modem to communicate through the Vodafone network.

### How to read your Advanced Meter.

It's super easy.

1. Your Advanced Meter's screen will automatically change its register display every six seconds. You can manually scroll through the registers by pressing the 'SELECT' button.
2. Your meter reading will appear on the screen.

If you have more than one price plan (i.e. 'Anytime' and 'Controlled') just repeat the steps above until you've got all the different meter readings.

### Getting to know your Advanced Meter.

What those letters and numbers really mean.

Every six seconds, the info displayed on your Advanced Meter's screen will change - in this order:



1 Test pattern. Ignore this, it's just the meter checking the display is working.



2 Your meter reading(s). You'll see either '24HR' or 'Ctrl' or 'nite' and 'day' as well as some figures and 'kWh'. This is how much electricity you've used so far.



3 For properties with more than one price plan, the reading for each plan will appear one after another in the display.



4 Your 'Current Load'. This is how much electricity you're using right now measured in kilowatts.



5 Signal strength. Your Advanced Meter sends your usage data to us wirelessly. This figure just says how strong the modem signal is.



6 Date display.



7 Time display.